


SCHEMATIC DIAG

1 2 3 4 5 6


A
B
C
D
E
F
G
H




Notes:

1. SW1-1: Hook switch in "ON-HOOK" position.
2. SW1-2: Hook switch in "ON-HOOK" position.
3. SW2: Dialing mode selector switch "TONE" position.
4. SW3: Ringer volume switch in "HIGH" position.

5. DC voltage measurements are taken with electronic voltmeter from negative terminal of battery.
(Add 40 mA to telephone line from the loop simulator.)
1 Off-hook condition
No Mark: Handset Mode
(): Speakerphone On Mode
6. This schematic diagram may be modified at any time with the development of new technology.





7. Important safety notice
 Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

